
Level Sensors Electromechanical Float Switches Types FS, Horizontal and Vertical Mount





Float switches for liquid level sensing Horizontal or vertical mount

Polypropylene, nylon, or polysulfone housings

Maximum switching voltage: 200 VDC or 240

VAC

Maximum switching current: 0.5 A (SPST) Suitable for specific gravities > 0.75

	- 2				
Prod	uct	Des	Cri	nti	on
1 100	400		U 11	~	U

Economical electrome- applications. Customer chanical float switches selectable normally for liquid level sensing. open or normally closed Various mounting con-switch function with figurations and housing switching capacity up to fit 50 W.

Ordering Key

FSH -24

Type _ Mounting attitude _____ Mounting type _ Housing material _____

Type Selection

materials most


Housing Material	Horizontal mount, Ø16 mm compression	Horizontal mount, 1/2" NPT thread	Vertical mount, 1/8" PF thread
Polypropylene	FSH-21	FSH-31	FSV-31
Nylon	FSH-24	FSH-34	FSV-34
Polysulfone	FSH-25	FSH-35	FSV-35

Specifications

Rated maximum switching voltage	200 VDC, 240 VAC	Connection	2 wires, XLPE 22 AWG x 12 in.
Rated maximum		Suitable specific	
current		gravity	>0.75
Switching	0.5 A	FS1 types	>0.80
Carrying	1.0 A	FS4 types	>0.85
7/22 850		FS5 types	
Rated max. switching		Housing material, color	
capacitiy	50 W (VA)	FS1 types	Polypropylene, black
		FS4 types	Nylon, grey
		FS5 types	Polysulfone, blue
Switch type, function	Reed, SPST	Approvals	UL, CE, ABS
Rated operating		Weight	
temperature		FSH1 types	35 g
FS1 types	-4 to +176°F	FSH4 types	38 g
FS4 types	-4 to +250°F	FSH5 types	40 g
FS5 types	-4 to +250°F	FSV types	18 g
Rated operating		5.50	
pressure			
FS1 types	57 ps i		
FS4/5 types	28 psi		



Dimensions



FSH-2. Lead Wire 30cm Hex18 LR


Lead Wire 30cm 1 1/8" PF Hex17 Magnet Hollow Float Drill hole \$10mm FSV-3.

FSH-3.

Installation Hints

FSH-.. types

Normally open or normally closed operation is selectable by orientation of the sensor in the tank. Normally open switching is obtained when the arrow on the mounting is pointed up, and vise verse, normally closed when the arrow is downward.



FSV-.. types Normally open or normally closed operation is selectable by inversion of the float on the shaft. The switches are shipped normally open unless otherwise indicated.

